

musical invention kit

Meet Ototo

	Specifications	4
	Before you get started	6
	Connecting objects	8
	Sounds	12
	Sensors	14
	MIDI	20
Projects		
	Not-So-Grand Piano	22

24

26

28

30

Musical Doorbell

A Light Breakfast

Water Drums

Pitch Balloon

Welcome to the world of Ototo!

With Ototo you can make music from anything, whether you're a musician creating new ways of interacting with sound, looking to use sensors to transform your next project or exploring music and electronics for the first time.


At *Dentaku*, we've spent years working in interaction design and electronic music, building interactive sound installations and inventions. We saw how difficult it was to create simple experiments and we wanted to create something that makes it easier for people to realise their musical interaction ideas.

This guide introduces you to the Ototo board, and shows you the basics of making sounds and how to use the different sensors with your board. There's some suggested projects from page 21, and while with Ototo you can get making sounds straight away, make sure to check out pages 6 and 7 to see what you can and can't do.


Use Ototo to power your imagination, leave traditional sounds behind and create something completely unexpected.

Let's make some noise!

Team Dentaku




Meet Ototo





- Connect a conductive material to a touch key using one of the crocodile clips.
 - 2. Press the *Up* and *Down buttons* at the same time so *Ototo* can detect that something new has
- 3. When you touch the material it will make a sound! Connecting a different material doesn't change the type of sound that is made; each touch key is a trigger.

At the bottom of the board there is a touch sensor with a set of 12 touch keys. Each touch key represents a musical note— when you touch *Ototo* it makes the sound of that note. Using the crocodile clips you can connect conductive materials and use them to trigger the notes.



The touch keys work by using a technology called capacitive sensing. This is similar to how many smartphone touch screens and laptop trackpads work. *Ototo* is measuring the capacitance on each of the touch keys. When touched by a human the capacitance on that touch key increases, we use this increase to trigger the sounds to play.

OO It works with anything that is electrically conductive— so it has to be a material that allows electricity to flow through it.

Lots of everyday materials such as aluminium foil, metal objects, and even pencil leads work a treat. The material only has to be slightly conductive, so plants, fruit, vegetables and water can also work! There is a wide range of specialised conductive fabric, thread, paint, ink, tape and more which are great to use with Ototo, but you can start with the objects around you right now.







Ototo comes with a library of sounds which are called presets.

You swap between these presets using the *Up* and *Down buttons*. Some presets you can play melodies on like a piano. Other presets are samples which play back a recorded sound, like a drum kit or science fiction sound effects.


Try out the different sounds for each thing you make, you may find the type of sound changes how you play your instrument.

OO Double press the Up or Down Buttons to change the pitch by an octave.



12

Sensors are add-on controllers which you can plug into Ototo. Each sensor changes the sound depending on how you interact with it.





Light






Touch Strip




















Ototo can also be used as a MIDI controller, meaning you can control things on a computer or other MIDI-compatible devices using Ototo's sensors. You could play a DJ set, play other synthesisers or control video and visual effects!

OO Simply connect Ototo to the computer using a Micro USB cable. Most music software already works with MIDI—look at its user manual or check out the Ototo website for help setting it up.






Projects

20 21







A Light Breakfast

your 0

1. Find a box and make a door that can open and close by cutting around three sides of the front of the box.

2. Along the edge of the box stick a strip of aluminium foil and connect it to Ototo using a crocodile clip then press the *Up* and *Down*

3. Connect a light sensor to one of the sensor inputs on *Ototo*, then place it inside the box securing it in place with some tape.

4. When you open and close the lid while touching the foil it will make a different sound.

• Try out connecting different sensor inputs and see what sounds you can get.



Balloon Pitch

1. Take one un-inflated balloon and make a tiny cut in one end around 1-2mm long. Insert the breath sensor so it is inside the balloon. Once the balloon inflates it will tighten around the sensor so the air won't leak out.

2. Attach the breath sensor to one of the sensor inputs on *Ototo*, blow up the balloon and tie it up. You don't have to inflate the balloon too much, the less inflated the balloon is the more sensitive it is. 3. Squeeze the balloon! Depending on which sensor input you've connected the sensor to you'll get different sounds. Try using it to alter the pitch to make lots of weird noises.





Now it's your turn!

We'd love to see and hear what you can come up with—so please drop us a tweet or an email and tell us how you're using Ototo.

Sharing your project with the world?
On Twitter use @Ototo to keep us informed!

For help and support or just thoughts and comments get in touch with us by emailing support@dentakulondon.com.

Check out our website to keep up with all of our latest discoveries in the world of Ototo.

www.ototo.fm

Ototo was made possible thanks to 915 *Kickstarter* backers

Illustration by Naomi Elliott
Printed by Art Quarters Press
Design and engineering by Dentaku, London

Ototo is a registered trademark of Dentaku Ltd.

Dentaku Ltd 2 - 4 Southgate Road London N1 3JJ

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE LINDESIRED OPERATION

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

